TYPE A: Applicable for normal load and assume adequate bearing conditions.
Invalid for soil with bearing capacity less than 0.5 tsf.



PLAN



SECTION A-A

SEPTIC TANK- TYPE A